

Midwest Driveshaft, Inc.

3712 Illinois Ave.,

St. Charles, IL 60174


(630) 513-9292 phone · (630) 513-9387 fax

www.mdsdriveshaft.com



Constructing a New Drive Shaft

This sheet applies to cars, 4 x4's, light duty trucks and high performance vehicles.



One of the diagrams below should apply for your application. Measurements must be taken with weight on suspension to determine the proper working length.





A




B




C




D



E



F



_____ A—Measure from tip of splined transmission output shaft to flat of flange rear differential

_____ B—Measure from tip of splined transmission output shaft to outside tip of differential yoke

_____ C—Measure outside tip of transmission yoke to outside tip of differential yoke

_____ D—Measure from flat of transmission flange to flat of flange rear differential

_____ E—Measure outside tip of transmission yoke to flat of flange rear differential.

_____ F—Measure flat of transmission flange to outside tip of differential yoke

* Yes No If the trans is a TH400 is the spline drilled and threaded at the end of the output shaft?

Name _____

Phone _____

Fax _____

Date _____